

Instruction Manual

Hand Truck



TROPL150S

SAFETY
SECTOR 

Product Overview



- 01 Push Handle
- 02 Load-Bearing Platform
- 03 Wheels

Product Accessories List



Load-Bearing Platform X1



Push Handle X1



Metal Washer (A) X4



Spring Lock Washer (B) X4



Nut (C) X4

Product Installation

1. Align the push handle with the mounting interface of the load-bearing platform and insert it (see illustration).



2. Place Metal washer (A), Spring lock washer (B) and Nut (C) sequentially onto the exposed threaded end of the push handle (see illustration). Tighten the Nut (C) to finish assembly.



LEGAL STATEMENT

This manual and its contents are protected under the Copyright Act 1968 (Cth). No part of this publication may be reproduced, distributed, modified, stored in a retrieval system, or transmitted in any form or by any means without the prior written permission of FRG Pty Ltd. Unauthorized use is strictly prohibited.

© 2026 FRG Pty Ltd. All rights reserved.



<https://www.safetysector.com.au/>